# Super Skim Coat hardening

# M651










## How to use

### Surface Preparation

- Clean the surface until the free from dust, oil, chemical and other contaminates to prevent the bonding strength of the adhesion.
- Remove all weak materials from the surface until the surface layer is strong enough.
- Treat the surface with water and let to semi-dry surface before applying with mortar.

### Application

- Mix 1 bag (20kg) of TPI M651 with 4 liters of clean water until mixture is homogenous.
- Apply on the cleaned surfaced with thin layer of Super Skim Coat hardening M651 and the required thickness is at least 1-3 mm. Or it can repair with plastering the cracks and to attend the roughness in order to make a smooth and more stronger surface.
- 4 hours after plastering, the plastered area is dried and it can be used.
- For the beautiful surface which is easy to clean, use with TPI Super Armour Nano Paint NP 301 Flooring (Top Coat –water based formula) which has clear and color products.

Usage Quantities : for package 20 kg

| Thickness of plastering (mm.) | Area (sq.m.) | Amount of mortar per 1 sq.m. (kg) |
|---|---|---|
| 1-3 | 4 | 5 |

Olive Green G09

Green G01

Dark Green G12

Red R01

Blue B01

Black E02

Brown E01

Yellow Y01

Natural N01

**Suitable for Repair with Thin Plastering on Crack, Hold or Gap.**